Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons

Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons

Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons

Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons

Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons

Disto-X2 Functions

Main Functions (single press and release):

- Power On / Turn Laser On / Take Reading
- Cancel Operation / Turn Laser Off
- Change Distance Reference
- Set Timer Duration / Start Timer (with Laser Off) (with Laser On)
- Enter Memory Mode - Show Saved Readings
- Scroll to Previous Reading / Increase Timer (in Memory Mode) (in Timer Mode)
- Scroll to Next Reading / Decrease Timer (in Memory Mode) (in Timer Mode)
- Show Device Information (Batt V, S/N, …)
- Show Extended Measurement Information

Secondary Functions (press and hold for 2 secs):

- Power Off
- Take a Reading (with Laser On)
- Change Distance Units
- Change Angle Units (Degrees/Grads)
- Turn Silent Mode On/Off (---)
- Turn Back-Sight Mode On/Off
- Turn Beep On/Off
- Turn Display Backlight On/Off
- Turn Triple-Shot-Check On/Off (◥)
- Change Distance Ref (Case/Endpiece)
- Calibration Mode Enter/Exit
- Clear Saved Readings from Memory
- Turn Bluetooth On/Off (ᛒ)
- Power Off and Lockout Buttons